

## Bluetooth Fingerprint Padlock











## I . USB Interface: The product is charged by USB.

Please fully charge the product for the first time.



## Components: 3.LED Light 4.Lock Beam

1.USB Port

III. Description Of First Administrator's Fingerprint Record


2.Fingerprint Reader


### II. Indicator Use 3-color indicator. Different indicator represents different devices and status.

Please check the details as below chart:

Indicator status Function

	LOW power	TX60 light lidon
	Charging	Green light always on
	Full charged	Lights off
	Green light flash	Fingerprint collection mode
	Green light always on	Successful to Register Fingerprint
	Blue light always on	Administrator fingerprint authorization
	Green light always on	Unlocked successfully
	Red light always on	Delete fingerprint mode
	Red light flash	Failed to collect fingerprint
rator's Fingerprint Pecerd		





VI.Specifications

The Android operating system can be downloaded on Google Play or by

V. Description Of Delete Fingerprint



V, the red indicator flash fast for 15s. If keep in the status of low batter, it will alarming per minute.

# Support 360 degree angel fingerprint recognize Resolution: 508DPI ESD: +/-12kV contact FRR: <1% FAR: <0.002% FAR: <0.002% Battery: 3.7V 300mAh Charger: 5V 0.5A

VIII. APP Operation Instructions

## LuckLock APP Compatible with iOS and Android Operating System,Connect with fingerprint lock via Bluetooth. Users can unlock fingerprints through LuckLock APP, Fingerprint addition, Fingerprint emptying, Fingerprint lock Users can unlock fingerprints through LuckLock APP, Fingerprint addition, Fingerprint emptying, Finger renaming, Fingerprint Lock Password Modification, Functions such as unlocking history view and so on. The method of use is as follows.:


Download and Install "LuckLock" App


(IOS system download in App Store, scanning the qr code below).

Google Play









## Coanning: Fingerprint locks that can scan nearby. Restore factory settings: Clear all the data and restore the initial state of the factory. disconnect:

Disconnect equipment from APP.

3. Function Introduction

interface, such as the right one:

Click on the top left corner  $\blacksquare$  icon, Enter the menu settings

You can add fingerprints, empty them and change passwords here.

③ Historical record: You can see which fingerprint was unlocked at what time.

Modify name:
 You can modify the current fingerprint lock name here.
 Password and Fingerprint:

- 4. APP Fingerprint Addition and Deletion Methods:
  - a. Click to add a fingerprint .

 $\ensuremath{\textcircled{1}}$  Use APP to add fingerprint method:

d. After five successful fingerprint acquisitions, the fingerprint lock "drops" loudly, and the APP interface quits the acquisition interface and returns to the password and fingerprint interface.

\*

 voice choice:
 Simplified Chinese / English / German / Russian / French
 Japanese / Spanish is optional. b. The following interface appears c. Successful single acquisition (Fingerprint lock green indicator flashes, indicating that fingerprints can be added) bright red screen fingerprint lines.



a. Click to empty your fingerprint.

2 Using APP to Delete Fingerprints:

b. Fingerprint lock "DING" loud, APP interface appears clear fingerprint success. At this point, all the fingerprints of the fingerprint lock are cleared. C password and Ingerprint

fingerprins

